

CHECK LIST FOR THE OMRON H5S TIME SWITCH

- 1) Open the bottom flap on the timer. The 3 small switches located on the lower left side should be set in the following order: UP, UP, DOWN.
- 2) Close flap.
- 3) The 2 switches located in the lower left hand corner of the face of the timer labeled "out" should be the "Auto" positions.
- 4) The switch in the lower right hand corner should be in the "Run" position.
- 5) The time should be on the display at this point. If not then set the time and press the "Write" key.
- 6) If you do not see the start and stop times on the bottom portion of the screen then the timer must be programmed.

PROGRAMMING

- 1) Slide the lower right hand switch from the "Run" position to the "P1" position.
- 2) Open the flap located at the bottom of the timer face.
- 3) Push and hold the small recessed bottom marked "CLR".
- 4) Next you have to determine the store hours and days operation. Typically store will run the same hours during the week. For this demonstration we will use the hours Mon-Sat 9-9, Sun 9-4.
- 5) Push the shift key once to move the arrow over to Mon. push the set/Reset key once .A bar should appear. Push the shift key again to move the arrow over to Tue. Push the Set /Reset key. Repeat this action for the rest of the days of the week except Sun.

Note: it is possible to skip a day of operation. Press the shift key once more to advance to another day.

- 6) Set the turn on time by pressing the "H" key.
- 7) Set the minutes by pressing the "M" key.
- 8) Press the "Write" Key.
- 9) Set the turn off time by pressing the "H" key and the "M" key. Press the write key.
- 10) There should be a "22" in the lower right hand portion of the display. This indicates that the first 2 programs (24 & 23). Were accepted.
- 11) To set the timers for Sunday, press the Set/Reset key and a bar will appear under Sunday.
- 12) Repeat Steps 6,7, & 8.
- 13) Slide the switch to "Run" position.
- 14) The green "Off" light should be lit on the Omron H3CR at this time.